



Bounce Back Target

ATTENTION:
2 adults recommended for assembly.

TOOLS REQUIRED (included):

Hex Wrench



Allen Wrench



GROUPINGS:

Group A: Target Assembly

- 2 - 2 3/4" bolts
- 4 - washers
- 2 - nuts

Group B: Front Brace Base

- Parts 1, 2
- 3 - 2" bolts
- 6 - curved washers
- 3 - hex nuts

Group C: Rear Brace Base

- Parts 3, 4
- 3 - 2" bolts
- 3 - hex nuts
- 6 - curved washers

Group D: Center Adjusting Brace

- Parts 9, 10
- 1 - knob handle bolt
- 1 - 2" bolt
- 1 - 1 3/4" bolt
- 4 - washers
- 2 - hex nuts

WARNING:
-Metal parts may have sharp ends.
-Never climb on the Bounce Back Target.
-Anchoring target with sandbags is recommended.

Hand tighten all nuts until Bounce Back Target is completely assembled. Then, retighten all bolts and nuts until secured.

Step 1

Follow GROUPINGS.
Unpack ALL parts. Layout pieces.

Step 2 Target Frame Assembly

CAUTION: While completing this step **DO NOT** let go of either part until you have inserted the bolts into the frame. Carefully fold out target, it will snap into a semi-locked position. Insert the 2 3/4" bolts into the frame on both sides. Secure bolt with washer and nut.

Step 3

Assemble front brace base using parts 1 and 2 as shown in diagram

Step 4

Assemble rear brace base using parts 3 and 4 as shown in diagram

Step 5

Connect Front and Rear stands to the target as shown in diagram

Step 6 Center Adjusting Brace

- Fasten part 9 (smaller diameter with indented lines) to rear of bottom cross bar of target with 1 3/4" bolt, washer and hex nut. Lines should be up.
- Screw knob handle into part 10
- Fasten part 10 to part 4 with 2" bolt, washer and hex nut.
- Adjust to desired angle and tighten knob handle.

Step 7

Secure elastic straps of cover to the corners of target. Hook clips to spring holders next to target.

Please use caution until you understand the speed of the Bounce Back ball return.

Do not leave Bounce Back Target outdoors when not in use, weather will effect the materials over a period of time.

